


Assembly instructions
inside

BETA**brite** Director™ Programming Manual



ADAPTIVE

© 1998-2001 Adaptive Micro Systems
Form No. 9702-2002B
2/9/01

NOTE: Due to continuing product innovation, specifications in this document are subject to change without notice.

Copyright © 1998-2001 Adaptive Micro Systems, Inc. All rights reserved.

The distinctive appearance of these products is a Trade Dress of Adaptive Micro Systems, Inc.

The following are trademarks of Adaptive Micro Systems: Adaptive, Alpha, AlphaNet plus, AlphaEclipse, AlphaPremiere, AlphaTicker, AlphaVision, AlphaVision InfoTracker, Automode, BetaBrite, BetaBrite Director, BetaBrite Messaging Software, Big Dot, PPD, Smart Alec, Solar, TimeNet.

Visit us at our Internet World Wide Web site:

<http://www.betabrite.com> or e-mail us at betabrite@ams-i.com

Contents

Installation and setup	1
Description	1
Overview	1
Technical specifications.....	2
EMI compliance	2
Assembling the Director	3
Assembly parts	5
How to mount a Director on a wall.....	6
How to mount a Director on a stand	7
How to attach the brochure rack to a BetaBrite Director (optional)	11
Connecting signs to a computer.....	13
Sending messages to the Director.....	14
Basic sign operation	15
Using the Remote Control	15
Turning a sign on and off.....	17
Setting a sign's time and date.....	18
Clearing a sign's memory	20
Setting a sign's password.....	21
How to set a password.....	21
What to do when you forget a sign's password.....	23
How to delete a sign's password	23
Using the Remote Control's sound control.....	24
Setting a sign's serial address	24
Beginning text messaging	26
Example 1 — Using upper and lowercase text	26
Example 2 — Displaying messages in PAGE name order (A, B, C, etc.).....	31
Example 3 — Displaying messages in time order	33
Example 4 — Changing the text of an existing message	36
Example 5 — Deleting messages	39
Advanced text messaging	40
Example 6 — Displaying the time and date	40
Example 7 — Using the FLASH mode to highlight information	44
Example 8 — Using fonts and colors	47
Example 9 — International characters	52
Appendices	53
Appendix A — Sign diagnostic test.....	53
Appendix B — Updating the sign's firmware (EPROM).....	54
Appendix C — Transferring a sign's memory from one sign to another.....	55
Quick Reference Card	56

Warranty

Adaptive Micro Systems, Inc. warrants to the original purchaser that the sign, keyboard and power supply will be free of defects in workmanship and materials for a period of one year from the date of purchase.

Adaptive Micro Systems, Inc. will without charge, repair or replace, at its option, defective product or component parts upon delivery to the factory service department accompanied by proof of the date of purchase in the form of a sales receipt.

This warranty does not apply in the event of any misuse or abuse of the product, or as a result of any unauthorized repairs or alterations. This warranty does not apply if the serial number is altered, defaced or removed from the sign. Incandescent lamps used in incandescent products are not covered by this warranty.

The purchase price of this product does not include, from Adaptive Micro Systems, Inc., any on-site support, service or maintenance.

Local ordinances prohibiting the use of flashing signs may exist in some locations. Compliance with local ordinances is the sole responsibility of the customer.

To obtain warranty coverage, this product must be registered. Please complete the enclosed warranty registration card and mail it to Adaptive Micro Systems, Inc.

How to obtain warranty service

1. Contact the distributor from whom the sign was purchased. If you do not know where the product was purchased, contact Adaptive Micro Systems Customer Service at 414-357-2020.
2. If the distributor cannot service the product, obtain a Return Merchandise Authorization (RMA) number through that company. An RMA number is required to obtain warranty service.
3. Fill out the Return Merchandise Authorization (RMA) Form on the following page. To obtain warranty service, this form including the RMA number must accompany the product.
4. Follow return instructions on the RMA form to return to Adaptive Micro Systems, Inc.

Return Merchandise Authorization (RMA) Form

RMA Number: _____

Date of Purchase: _____

Company Name: _____

Contact Person: _____

Address: _____

Phone Number: _____

Fax Number: _____

Description of Problem: _____

Return Instructions

1. Obtain an RMA number from your distributor.
2. Fill out this form and include proof of purchase receipt if product is under warranty.
3. Pack this form, the sign, keyboard and transformer in the original carton (or a suitable replacement). Please write the RMA number on the outside of the package. Any damage to the product during shipment is the responsibility of the freight company or the owner of the sign.
4. Ship the package, **postage/shipping prepaid** to:

Adaptive Micro Systems, Inc.
Attn: RMA No. _____
7840 North 86th Street
Milwaukee, WI 53224

**PLEASE WRITE THE RMA NUMBER ON THE LABEL OF THE SHIPPING BOX.
THANK YOU.**


Installation and setup

The Director is an indoor LED sign that can display up to eight 16-character rows of text. The sign is capable of storing up to 26 “pages”, or screens, of text information.

The sign can either be hung from a wall or mounted on a stand. When mounted on a stand, an optional brochure rack can be placed beneath the sign.

Description

Overview



Item	Name	Comments
A	Director	LED sign
B	Mounting bracket	This is a factory-installed option if the sign is to be wall-mounted. (The mating bracket for the wall must be user-installed.)
C	RS232/RS485 jacks	The sign's bottom panel tips up to expose the RS232/RS485 jacks used to connect the sign to a computer. (See page 13.)
D	Electrical socket and cable	See "Technical specifications" below.
E	Floor mount stand with crossbar	This is a user-installed option if the sign is to be free-standing.
F	Brochure rack	This is an option.


Technical specifications

Power	115/230 VAC, 150 W, 50/60 Hz
Dimensions	22.5L x 3.12D x 27H (57.2L x 7.9D x 68.6H cm) without brochure rack and stand
	27L x 18D x 61H (68.6L x 45.7D x 154.9H cm) with brochure rack and stand
Weight	31.1 lbs. (14.1 kg) without brochure rack and stand
	46.5 lbs. (21.1 kg) with brochure rack and stand

EMI compliance

This equipment has been tested and found to comply with the limits for a Class A digital Device, pursuant to Part 15 of the FCC Rules. These limits are designated to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Assembling the Director

⚠ WARNING	
	<p>Hazardous voltage. Contact with high voltage may cause death or serious injury. Always disconnect power to sign prior to servicing.</p>

⚠ WARNING	
	<p>Fasten sign to floor. Otherwise sign may tip over causing serious injury or death.</p>

NOTE: Do NOT use the Director outdoors because water and dust will damage the sign.

NOTE: Because of its size and weight, the Director should be assembled by two people.


Setting the RS232/RS485 jumper

Using the directions that follow, be sure the jumper in the Director is set as needed:

To connect a sign to...	set the jumper to...
one computer	RS232
a sign network	RS485

1. Remove power from the sign.


- 2. Remove one screw from each of the L-brackets holding the sign's cap.
- 3. Lift up and remove the cap.
- 4. Pull up and remove the clear plastic lens on the sign's front.



- 5. To remove the jumper, grasp it with needle-nosed pliers and gently pull it out.

Place it on the 2 *left* posts for RS232, as shown here.


Place it on the 2 *right* posts for RS485.



- 6. Replace the plastic lens on the sign's front, being careful not to catch any wires.
- 7. Replace the sign's cap and L-brackets and then re-apply power to the sign.

Assembly parts


These are in addition to the primary components shown on page 1. These are not drawn to scale.



Part	Quantity	Component
A	1	Wall-mounting bracket, end view and face view
B	1	Crossbar
C	2	Hex (Allen) wrench: 1 smaller and 1 larger
D	2	Safety stop block, end view and face view
E	4 2	3/8" long Phillips screw and Post cap
F	4	Shoulder bolt for optional brochure rack, end view and side view (3/4" shoulder, 1-5/16" total length)
G	3	Tie wrap


How to mount a Director on a wall

1. Make sure a mounting bracket is attached to the back of the sign:



2. Attach the wall-mounting bracket (supplied) to a wall. Then hang the sign from this bracket.


NOTE: Only hang the Director from a wall capable of supporting 116 pounds (52.5 kg). Use fasteners (not supplied) also capable of supporting 116 pounds.




3. Plug the power cord into the sign and route it from the sign in such a way that it is not in an area where people will be walking.

How to mount a Director on a stand


1. Lay the two mounting poles for the stand on a flat surface. Slide the crossbar down the channels on the mounting poles.



2. Slide a safety stop down each channel:




- Use the smaller Allen/hex wrench to tighten the crossbar to each mounting pole with the four pre-installed set screws. Then use the same wrench to tighten each safety stop with its two set screws, also pre-installed in each:




NOTE: Screws should be securely tightened.
(18 to 20-inch/pounds of torque recommended).

- Place each of the sign's mounting brackets in a channel on each mounting pole. Then slide the sign down until it rests on the safety stops. Finally, attach the post caps onto the tops of the mounting poles using two of the 3/8" Phillips screws supplied for each.



5. Fasten the sign to the floor using four bolts or screws (not supplied) in the locations shown below:




Top view of sign

6. Plug the power cord into the back of the sign. Route the cord from the sign in such a way that it is not in an area where people will be walking.

Run the power cord along one of the mounting poles.

Use the 3 supplied cable ties to fasten the power cord to the mounting pole. Cut off excess cable tie length.


Fasten the power cord to the floor in such a way (e.g., tape) as to prevent someone from tripping over the cord.




*Completed assembly of sign
Shown without the optional brochure rack*

How to attach the brochure rack to a BetaBrite Director (optional)


1. Using the larger Allen/hex wrench, attach the four shoulder bolts to the legs of the sign:



2. Slip the plastic brochure rack over the four shoulder bolts. Then push the brochure rack down to secure it in place.



3. Use the supplied plastic dividers as needed in the brochure rack to adjust for different sizes of literature.




Connecting signs to a computer

Connect the sign to a computer (as follows) in order to send messages to the sign using that computer running Adaptive messaging software. For a list of valid software, see “Sending messages to the Director” on page 14.

Connecting a single sign to a computer

1. Remove power from the sign.
2. Be sure the sign’s internal RS232/RS485 jumper is set to RS232. (See “Setting the RS232/RS485 jumper” on page 4.)
3. Connect a personal computer to the sign as shown:



Connecting multiple signs into a network

For this type of networking, the sign’s internal RS232/RS485 jumper must be set to *RS485*. (See “Setting the RS232/RS485 jumper” on page 4.)

Because there is such a wide variety of ways (e.g., LAN, wireless, etc.) to connect networked signs, see the **Network Configurations** manual, PN 9708-8046, for more information.

You may wish to assign a unique serial address to a sign. This allows you to send messages to that particular sign when located on a network with other signs. See “Setting a sign’s serial address” on page 24 for details.

Sending messages to the Director

Messages can be sent to the Director signs with either of two methods.

One way is to use messaging software:

- BetaBrite Messaging Software
- Alpha Messaging Software
- AlphaNET *plus*
- Smart Alec
- ActiveX

This user manual does not discuss usage of messaging software. Please refer to the specific software manual for more information.

The other way messages can be sent to the Director signs is by using the hand-held Remote Control. This method is discussed in “Beginning text messaging” on page 26 and “Advanced text messaging” on page 40 of this manual.

Basic sign operation

Using the Remote Control

The Remote Control is a hand-held keyboard which emits infrared light and is used to program a sign. The Remote Control needs four AAA batteries to operate. They should be installed in the back of the control.

The Remote Control can be used to turn a sign on/off or to set its serial address. It can also be used to set its time and date and to clear memory.

However, the Remote Control's most important—and most used—purpose is the creation of text messages and graphic images on a sign.

To show you how to use the Remote Control, this manual presents practical, everyday examples.

NOTE: A sign (or a network of signs) can also be programmed using a personal computer and special software. (See the document **Network Configurations**, PN 9708-8046, and your messaging software user manual for more detailed information.)





Figure 1: Infrared (IR) Remote Control keyboard

To use the Remote Control:

- Stand at least 5 feet and no more than 30 feet from the sign.
- Make sure nothing reflective is in front of the sign. (Light from the sign’s display that is reflected back can interfere with the Remote Control.)
- If nearby fluorescent lights interfere with the Remote Control, you may have to relocate either the lights or the sign.



If a sign is this far from the floor...	...then hold the Remote Control this far away:
10 feet	from 10 to 30 feet
15 feet	from 19 to 30 feet
20 feet	from 25 to 30 feet

Figure 2: Using the Remote Control with a sign

Turning a sign on and off


When you plug in the sign's power supply, the sign starts up automatically, and unplugging the power supply turns the sign off.

However, instead of unplugging a sign, there is another way to turn a sign off:

Using the Remote Control, hold down *SHIFT* and then press *PROGRAM* to turn a sign off and on.





NOTE: Messages that you have programmed into the sign will *not* be lost when you turn a sign off. Messages will be retained for up to 30 days if the sign is not powered.






When you turn a sign on, information similar to the following will be displayed:



Setting a sign's time and date






Once set, a sign will remember the time and date for up to 30 days even if the sign is unplugged or interrupted by a power loss. This is because it is equipped with a battery-backed real-time clock.

Step	When you do this...	You see this...
1	Press PROGRAM .	 <p style="text-align: center;">PROGRAM MODE</p> <p style="text-align: center;">THEN</p>  <p style="text-align: center;">PAGE A MODE: [AUT] SPEED: [SP4]</p>
2	Press BACK until SET TIME AND DAY appears.	 <p style="text-align: center;">SET TIME AND DAY</p>
3	Press ADV .	 <p style="text-align: center;">SET W/ D, H&M TUESDAY 3:54 PM</p>

4	<p>Press D to set the day of the week. Press H to set the hour. Press M to set the minute.</p> <p>NOTE: Press SELECT, to change from 12-hour (AM/PM) to 24-hour mode (0 - 23).</p>	
5	<p>Press BACK until SET DATE appears.</p>	
6	<p>Press ADV.</p>	 
7	<p>Press D to set the correct day. Press M to set the month. Press Y to set the year.</p> <p>NOTE: Press SELECT to display the date in different formats—for example, JAN 26, 2001 or 1/26/01, or 26/1/01, etc.</p>	
8	<p>After setting the date and time, press RUN twice to return to normal operation.</p>	

Clearing a sign's memory

NOTE: Clearing a sign's memory erases the password and all messages that have been programmed into the sign.

Step	When you do this...	You see this...
1	Press PROGRAM .	 <p style="text-align: center;">PROGRAM MODE</p> <p style="text-align: center;">THEN</p>  <p style="text-align: center;">PAGE A MODE: [AUT] SPEED: [SP4]</p>
2	Press BACK until CLEAR MEMORY appears.	 <p style="text-align: center;">CLEAR MEMORY</p>
3	Press ADV.	 <p style="text-align: center;">WARNING *****</p> <p style="text-align: center;">THEN</p>  <p style="text-align: center;">CLEAR ALL? Y/N</p>
4	Press Y to clear the sign's memory. The sign will return to normal operation and display a series of demo messages.	





Setting a sign's password








You can set a personal password to protect your messages from tampering by others.

NOTE: DON'T FORGET YOUR PASSWORD! If you do, you won't be able to operate the sign.




However, *if you do forget the password*, see "What to do when you forget a sign's password" on page 23.

How to set a password

Step	When you do this...	You see this...
1	Press PROGRAM .	 <p>PROGRAM MODE</p> <p>THEN</p>  <p>PAGE A MODE: [AUT] SPEED: [SP4]</p>
2	Press BACK until SET PASSWORD appears.	 <p>SET PASSWORD</p>
3	Press ADV .	 <p>PASSWD Y/N</p>

<p>4</p>	<p>Press Y to set a password.</p>	
<p>5</p>	<p>Type a 6-character password. (Only asterisks will appear on the sign as you type.)</p> <p>Re-type the password when prompted.</p> <p>CORRECT will appear if you entered the same password.</p> <p>If you failed to type the same password, ERROR will appear, and you'll have to start over from Step 1.</p>	 <p>THEN</p>  <p>THEN</p>  <p>THEN</p> 
<p>6</p>	<p>Press RUN twice.</p>	
<p>7</p>	<p>Press Y to password protect the sign.</p> <p>NOTE: If you select N, then a password will not be needed when you press PROGRAM.</p>	 <p>THEN</p> <p>The sign will return to normal operation.</p> <p>Now, whenever you press PROGRAM, you'll have to type the password you just entered.</p>

What to do when you forget a sign's password

Step	When you do this...	You see this...
1	Press PROGRAM .	
2	Hold down SHIFT and press L six times.	 <p data-bbox="740 509 785 532">THEN</p> 
3	Enter a new password. (See "Setting a sign's password" on page 21.)	

How to delete a sign's password

If you no longer want to be prompted to password protect a sign, you must clear the sign's memory in order to delete the password. To do this, see "Clearing a sign's memory" on page 20.




Using the Remote Control's sound control


Normally, whenever you press a Remote Control key, the sign will beep. This lets you know that an action has been performed. To turn this feature off (or on again), hold down **SHIFT** and press **RUN**.

Setting a sign's serial address

The serial address is a number that you can assign to a sign. Typically this feature would be used for a sign that is connected to other signs on a network. Giving a unique serial address to a sign allows you to send messages to that *particular* sign.

See the document **Network Configurations**, PN 9708-8046, for more detailed information on networking signs.

Step	When you do this...	You see this...
1	Press PROGRAM .	
2	Press BACK until SET SERIAL ADDRESS appears.	
3	Press ADV .	


4	<p>Type a number, like <i>10</i>.</p> <p>NOTE: A serial address is actually a number from 0 to 255 in <i>hexadecimal</i> (00 to FF). However, in typical use entering a number from 00 to 99 is fine.</p> <p>NOTE: When a sign leaves the factory, its serial address is set to 00.</p>	 A rectangular digital display with a black background and white text. The text reads "SERIAL ADDRESS =" on the top line and "10" on the line below. The display is framed by a double-line border.
5	Press RUN twice to set the new serial address and return the sign to normal operation.	



Beginning text messaging






This section shows you how to start creating messages on your sign.







Example 1 — Using upper and lowercase text







In this first example, you'll display the following text on the sign:



Step	When you do this...	You see this...
1	Press PROGRAM .	<p>Modes allow you to use a special effect, like flashing, on a message. In this case, Automode [AUT] is used. To change MODE, hold down SHIFT and press either 2 (WIPE), 4 (FLASH), 5 (HOLD), or 7 (AUTO).</p> <p>SPEED controls how fast a mode changes. To change SPEED, hold down SHIFT and press 8. [SP5] is the fastest speed and [SP1] is the slowest. [NHL] means "no hold".</p> 
2	Press ADV .	<p>Blinking cursor</p> 

3	<p>Type <i>THIS IS YOUR</i></p> <p>NOTE: If you make a mistake while typing, press BACK to erase a letter.</p>	
4	<p>Press RETURN to start on the next line.</p>	
5	<p>Type <i>FIRST MESSAGE.</i></p> <p>NOTE: To create the period (.), hold down SHIFT and press X.</p>	
6	<p>Press RUN to display your first message.</p>	<p>Because Automode [AUT] was used, the message will appear in different colors.</p> 
<p>Here's how to create the second message:</p>		
7	<p>Press PROGRAM.</p>	




<p>8</p>	<p>Press B to switch to PAGE B.</p>	<p>Your second message will be created in PAGE B. →</p> <p>(Your <i>first</i> message is still in PAGE A. You can create up to 26 separate messages using pages A through Z.)</p> 
<p>9</p>	<p>Hold down SHIFT and then press 2 for WIPE.</p>	 <p>← WPUP = wipe up.</p> <p>If you hold down SHIFT and press 2 again, the MODE would change to WPDN (wipe down). You can also select wipe left and wipe right.</p>
<p>10</p>	<p>Press ADV</p>	
<p>11</p>	<p>Press the round COLOR key until the cursor color stays green.</p>	
<p>12</p>	<p>Type <i>T</i></p>	
<p>13</p>	<p>Press CAPS to change to lowercase text.</p> <p>Then type <i>his is your</i></p>	<p>All these characters in this line should be <u>green</u>. →</p> 




14	Press RETURN to go to the next line.	
15	Press the round COLOR key until the cursor color stays red.	
16	Type <i>second message</i> .	<p>All these characters in this line should be <u>red</u>.</p> 
17	Press RETURN to go to the next line.	
18	Press the round COLOR key until the cursor color stays amber.	
19	<p>Using CAPS, SHIFT, and RETURN when necessary, type the following: <i>The CAPS key changes between upper & lower case.</i></p> <p>NOTE: The ampersand (&) is made by holding down SHIFT and pressing K.</p>	<p>All these characters in these lines should be <u>amber</u>.</p> 

Here's how to insert a blank line between the two sentences above:		
<p>20</p>	<p>Hold down SHIFT and press E to move the cursor up one line.</p> <p>Repeat this until the cursor is over the A in CAPS.</p>	
<p>21</p>	<p>Press INSERT to create a blank line.</p>	<p>Use INSERT to create blank lines between text. →</p> <p>(Use DELETE to remove blank lines.)</p>
<p>22</p>	<p>Press RUN to see the message.</p>	<p>Notice that only the second message (PAGE B) is displayed.</p> <p>In the next example, you'll see how to display multiple messages instead of just one.</p>

Example 2 — Displaying messages in PAGE name order (A, B, C, etc.)

Once you've programmed messages into the sign, you may want to set the order or sequence in which messages appear. This method will display messages by their PAGE name (A, B, C, etc.) in the order you set (C, A, B, for example.) If you do not set the sequence, the messages will appear in alphabetical order.



Step	When you do this...	You see this...
This example continues where Example 1 left off. This example assumes that there are two messages (PAGE A and B) in the sign.		
1	Press PROGRAM .	<p>Since we're continuing from Example 1, this would appear on the sign.</p> 
2	Press RUN .	<p>DEMO or RUN may also appear here. →</p> <p>TIM</p> <p>TIM = used to display messages in time order DEMO = displays a set of demonstration messages. RUN = used to display messages by PAGE order (A, B, C, etc.)</p> 
3	<p>If RUN appears on the sign, go to the next step.</p> <p>Otherwise, press SELECT until RUN appears.</p>	








<p>4</p>	<p>Press B and then A</p>	<p>This will be the order (PAGE B, then PAGE A) in which messages are displayed on the sign.</p> 
<p>5</p>	<p>Press RUN.</p>	<p>PAGE B message</p>  <p>PAGE A message</p>  <p>These two messages will keep being displayed in this order until a new PAGE order or a new message is entered.</p>
<p>Using this method, you can program the order of some or all of the messages you've entered on a sign.</p>		



Example 3 — Displaying messages in time order

In Example 2, you set the order of messages by PAGE letter (A, B, C, etc.). However, that method could not specify an exact time when a message would appear.

In this example, we'll show you how to make a message start and stop at times you specify.





Step	When you do this...	You see this...
<p>For this example, make sure that your sign's internal clock has been accurately set. (See "Setting a sign's time and date" on page 18.)</p> <p>This example continues where Example 1 left off. This example assumes that there are two messages (PAGE A and B) in the sign.</p> <p>In this example, we'll program the sign to display the message in PAGE A on Monday through Friday from 1:20 PM to 1:30 PM. We'll program the sign to always display the message in PAGE B.</p>		
1	<p>Press PROGRAM.</p> <p>(If PAGE B does not appear, press B to display it.)</p>	<p>Since we're continuing from Example 1, this would appear on the sign.</p> 
2	<p>Hold down SHIFT and press 9 for TIME.</p>	<p><i>ON ALWAYS</i> is the default setting for a message. A message set to <i>ON ALWAYS</i> will run continuously.</p>  <p>Since PAGE B is already set up, we'll go on to PAGE A.</p>







3	<p>Press RUN twice.</p> <p>Then press PROGRAM.</p>	
4	<p>Press A.</p>	
5	<p>Hold down SHIFT and press 9 for TIME.</p>	
<p>First we'll set the ON time — or when this message will start on the sign:</p>		
6	<p>Press D (for day) until <i>MO-FR</i> appears.</p>	 <p>Press D to set the day, H for hour, and M for minute (in 10-minute increments).</p>
7	<p>Press H (for hour) until <i>13:00</i> appears.</p>	 <p>Hours are represented in 24-hour or military style. So 1:00 PM = 13:00, 2:00 PM = 14:00, etc.</p>
8	<p>Press M (for minute) until <i>13:20</i> appears.</p>	 <p>Minutes are in increments of 10.</p>
9	<p>Press SELECT.</p>	 <p>After setting the ON time, we'll select the <i>OFF</i> time or when the message <u>stops</u>.</p>
10	<p>Repeat Steps 6, 7, and 8 to set an <i>OFF</i> time (in this case, 13:30)</p>	






11	Press RUN twice.	<p data-bbox="394 305 506 378">This message should appear continuously.</p> <p data-bbox="557 315 578 375">PAGE B</p>  <p data-bbox="394 634 519 753">This message should only appear <u>between</u> the <i>ON</i> and <i>OFF</i> times you set.</p> <p data-bbox="557 667 578 727">PAGE A</p> 
----	-------------------------	--

Example 4 — Changing the text of an existing message

After typing in a message, you may want to add or remove text from it. The following is an example of this common situation:

Step	When you do this...	You see this...
<p>This example continues where Example 2 left off. This example assumes that there are two messages (PAGE A and B) in the sign.</p> <p>In this example, we'll change PAGE A to the following: <i>THIS IS YOUR VERY FIRST MESSAGE, BUT NOW IT'S LONGER</i></p>		
1	Press PROGRAM .	
2	Press RUN . Press SELECT until RUN appears. Press A and then B to set a run sequence. Finally, press RUN again.	
3	Press PROGRAM . (If PAGE A is not displayed, press A .)	
4	Press ADV .	<p>The cursor should be blinking over the first letter.</p> 





5	Hold down SHIFT and press C to move the cursor down one line.	<p>How to move the cursor:</p> <p style="text-align: center;">  </p> <p>The cursor should be blinking over the first letter on the second line.</p> 
6	Try to type the word <i>VERY</i>	<p>You'll only be allowed to type the first two letters of <i>VERY</i>, because there must be enough room in a line to add the characters.</p> 
7	<p>In order to make room for the word <i>VERY</i>, you'll have to delete the word <i>MESSAGE</i> first.</p> <p>Move the cursor to the end of the word <i>FIRST</i> by holding down SHIFT and then pressing F.</p>	
8	Press DELETE until the word <i>MESSAGE</i> (and the period) is deleted.	
9	Hold down SHIFT and press D to move the cursor over the letter <i>F</i> .	

<p>10</p>	<p>Finish the word <i>VERY</i> by typing <i>RY</i> and a space.</p>	
<p>11</p>	<p>Hold down SHIFT and press C to move down one line. Then hold down SHIFT and press D until the cursor is at the start of the line.</p>	
<p>12</p>	<p>Type <i>MESSAGE, BUT NOW</i></p>	<p>The cursor moves to the next line automatically.</p> <p>Use SHIFT + W to create a comma.</p> 
<p>13</p>	<p>Type <i>IT'S LONGER</i></p>	<p>Use SHIFT + V to create an apostrophe.</p> 
<p>14</p>	<p>Press RUN to see your message.</p>	

Example 5 — Deleting messages

To delete all the messages in a sign, see “Clearing a sign’s memory” on page 20.




However, if you only want to delete selected messages, then use the method shown in this example.






Step	When you do this...	You see this...
<p>This example continues where Example 4 left off.</p> <p>This example assumes that there are two messages (PAGE A and B) in the sign: PAGE A = <i>THIS IS YOUR VERY FIRST MESSAGE, BUT NOW IT'S LONGER</i> PAGE B = <i>This is your second message. The CAPS key changes between upper & lower case.</i></p> <p>In this example, we'll delete the PAGE B message:</p>		
1	Press PROGRAM . (If PAGE B is not displayed, then press B .)	
2	Press DELETE .	
3	Press Y to delete the page.	
4	Press RUN twice.	<p>Only the PAGE A message should appear.</p> 

Advanced text messaging

Before attempting the following, make sure you're familiar with the previous examples in the "Beginning text messaging" section of this manual.

Example 6 — Displaying the time and date

Step	When you do this...	You see this...
<p>In this example, we'll create a message that continuously displays the current time and date:</p>		
<p>Current date and time (displayed in <i>amber</i>)</p> <p>This will be displayed in <i>red</i>.</p> <p>This will be displayed in <i>green</i>.</p>		<p>PAGE A</p> <p>(The <i>first</i> message you'll enter.)</p>
<p>Current date and time (displayed in <i>amber</i>)</p> <p>This will be displayed in <i>red</i>.</p> <p>This will be displayed in <i>green</i>.</p>		<p>PAGE B</p> <p>(The <i>second</i> message you'll enter.)</p>
<p>1</p>	<p>Delete all the messages currently stored in the sign. (See "Clearing a sign's memory" on page 20 or "Example 5 — Deleting messages" on page 39.)</p>	
<p>2</p>	<p>Press PROGRAM.</p> <p>(If PAGE A is not displayed, just press A.)</p>	

3	<p>Change the MODE to Wipe Down.</p> <p>Set the message transition speed to its fastest — SP5.</p>	
4	<p>Press ADV.</p> <p>Press COLOR until the cursor always blinks <u>amber</u>.</p> <p>Then press SPACE to move the cursor over two spaces.</p>	
Here's how to put the <i>date</i> in the message:		
5	<p>Hold down SHIFT and press 0.</p>	
6	<p>Press RETURN to start on a new line.</p> <p>Press COLOR until the cursor always blinks <u>amber</u>.</p> <p>Then press SPACE four times to move the cursor over.</p>	
Here's how to put the <i>time</i> in a message:		
7	<p>Hold down SHIFT and press 9.</p>	

Now enter the rest of the PAGE A message:

8 Press **RETURN** twice to skip down two lines.

Press **COLOR** until the cursor always blinks red.

Using **CAPS** when necessary, type *Room*, a space, and then *Company*




9 Press **RETURN** again to start on a new line.

Press **COLOR** until the cursor always blinks green.

Using **CAPS** when necessary, type *E101*, a space, and then *Applied Eng*.

Repeat this process for the remaining lines of text.




10 Press **PROGRAM**.

Press **B** to go to PAGE B.

Change the MODE to Wipe Left [WPLF].

Change the SPEED to the fastest [SP5].




← Use **SHIFT + 2** to change the MODE.




← Use **SHIFT + 8** to change the SPEED.

11 Press **ADV**.



12 Using what you've just learned, enter the PAGE B message as shown:









13	Press RUN .	
14	Press SELECT until RUN appears.	
15	Type A and then B to set the order in which the two messages will appear.	
16	Press RUN again to display the two messages.	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="display: flex; align-items: center; margin-bottom: 20px;"> <div style="margin-right: 20px;">PAGE A message</div> <div style="border: 1px solid black; padding: 10px; text-align: center;"> <p>APR. 17, 2001 1:37 PM</p> <p>Room Company E101 Applied Eng E200 United Wire W20 ACME Tool W130 Adv Maint</p> </div> </div> <div style="display: flex; align-items: center; margin-bottom: 20px;"> <div style="margin-right: 20px;">PAGE B message</div> <div style="border: 1px solid black; padding: 10px; text-align: center;"> <p>APR. 17, 2001 1:37 PM</p> <p>Room Company S200 Generic Mfg S250 Bob's Print</p> </div> </div> </div>

Example 7 — Using the FLASH mode to highlight information

FLASH is a mode that you shouldn't overuse. However, it is very handy if you want to call attention to a single item, like a time or room number, on a page:

Step	When you do this...	You see this...
<p style="text-align: center;">In this example, we'll continue from the previous example:</p> <div style="display: flex; align-items: center;"> <div style="flex: 1;"> <p>To call attention to this room number, we'll make it flash on and off.</p> </div> <div style="flex: 2; border: 1px solid black; padding: 10px;"> <pre style="font-family: monospace; background-color: black; color: white; padding: 5px;"> APR. 17, 2001 1:37 PM Room Company E101 Applied Eng E200 United Wire W20 ACME Tool W130 Adv Maint </pre> </div> </div>		
<p style="text-align: center;">1</p>	<p>Press PROGRAM.</p> <p>(If PAGE A is not displayed, then press A.)</p>	<div style="border: 1px solid black; padding: 10px; text-align: center;"> <pre style="font-family: monospace; background-color: black; color: white; padding: 5px;"> PAGE A MODE: [WPDN] SPEED:[SP5] </pre> </div>
<p style="text-align: center;">2</p>	<p>Press ADV.</p>	<div style="display: flex; align-items: center;"> <div style="flex: 1;"> <p>Blinking cursor</p> </div> <div style="flex: 2; border: 1px solid black; padding: 10px;"> <pre style="font-family: monospace; background-color: black; color: white; padding: 5px;"> ■ APR. 17, 2001 1:37 PM Room Company E101 Applied Eng E200 United Wire W20 ACME Tool W130 Adv Maint </pre> </div> </div> <p>Since this continues where the last example, left off, this is what should appear for PAGE A.</p>

3	Press A .	 <pre> ■ APR. 17, 2001 1:37 PM Room Company E101 Applied Eng E200 United Wire W20 ACME Tool W130 Adv Maint </pre>
4	Hold down SHIFT and press C until the cursor is over the letter W in W20.	<p>Move the cursor here. →</p>  <pre> APR. 17, 2001 1:37 PM Room Company E101 Applied Eng E200 United Wire ■W20 ACME Tool W130 Adv Maint </pre>
5	Hold down SHIFT and press 4 for FLASH.	<p>This entire line should now be flashing. →</p>  <pre> APR. 17, 2001 1:37 PM Room Company E101 Applied Eng E200 United Wire ■W20 ACME Tool W130 Adv Maint </pre>

<p>6</p>	<p>Move the cursor to in front of ACME Tool.</p>	<p>Hold down SHIFT and press F to move the cursor.</p> 
<p>7</p>	<p>Hold down SHIFT and press 4. This turns flashing off for the rest of the line.</p>	<p>Now the only text flashing should be the room number — W20.</p> 
<p>8</p>	<p>Press RUN to see the message.</p>	

Example 8 — Using fonts and colors


Fonts are the way characters are displayed on a sign. In the world of printing and publishing, fonts are given names like Times or Helvetica and qualities like serif or sans serif, font size (like 12 point or 14 point), bold or italic, etc.

This sign can display two types of fonts:

Upper- *and* lowercase letters can be used with this font. —————> This is the first font.


Only upper-case letters can be used with this font. —————> THIS IS THE SECOND FONT





This is the message we'll create using both of the sign's fonts.













To change from one font to the other, press the **FONT** key.


The following examples demonstrate how to use fonts on a sign:

Step	When you do this...	You see this...
1	Press PROGRAM . (If PAGE C is not displayed, just press C .) Using SHIFT + 5 , change the MODE to Hold.	

<p>2</p>	<p>Press ADV.</p>	
<p>3</p>	<p>Type in the following message.</p>	
<p>4</p>	<p>Move the cursor in front of the <i>"The potentate</i> Then press FONT.</p>	<p>Pressing FONT → changes the entire line to a different font. (Pressing FONT again would restore the original font.)</p> 
<p>5</p>	<p>Move the cursor in front of the word <i>potentate</i> Press FONT. All the text after the cursor should change to the other font.</p>	<p>The FONT key can be used to change a whole line of text or just a single word.</p> 

6	<p>Press FONT again to make the whole line the same font.</p> <p>Then position the cursor in front of the remaining lines and change the font of each line.</p>	
7	<p>Press RUN to see your message.</p>	
Here's a demonstration of what colors can be used:		
8	<p>Press PROGRAM.</p> <p>(If PAGED is not displayed, just press D.)</p> <p>Using SHIFT + 5, change the MODE to Hold.</p>	
9	<p>Press ADV.</p>	

<p>10</p>	<p>Type <i>COLOR 0</i> Then press RETURN.</p>	<p>COLOR 0 should be <u>red</u> to start. When displayed in the message, it will cycle through several color schemes.</p>	
<p>11</p>	<p>Press COLOR one time. Type <i>COLOR 1</i> Then press RETURN.</p>	<p>COLOR 1 should be <u>red</u>.</p>	
<p>12</p>	<p>Press COLOR two times. Type <i>COLOR 2</i> Then press RETURN.</p>	<p>COLOR 2 should be <u>green</u>.</p>	
<p>13</p>	<p>Press COLOR three times. Type <i>COLOR 3</i> Then press RETURN.</p>	<p>COLOR 3 should be <u>amber</u>.</p>	
<p>14</p>	<p>Press COLOR four times. Type <i>COLOR 4</i> Then press RETURN.</p>	<p>COLOR 4 should be <u>multi-colored</u> with the same combination of colors for each character.</p>	
<p>15</p>	<p>Press COLOR five times. Type <i>COLOR 5</i> Then press RETURN.</p>	<p>COLOR 5 should be <u>multi-colored</u> with a different combination of colors for each character.</p>	

16	<p>Press COLOR six times.</p> <p>Type <i>COLOR 6</i></p> <p>Then press RETURN.</p>	<p>Each character in COLOR 6 → should be a different color.</p> 
17	<p>Press RUN to see what all the colors look like in a running message.</p>	


Example 9 — International characters

International characters—like ü and é—can be included in messages.

NOTE: International characters can not be used with the small font.

If you try, a question mark (?) will appear in place of the letter.




The following table summarizes all the international characters that can be used:

											
Base Characters	(Use the CAPS button on the Remote Control for upper-case vs. lower-case letters.)										
	A	C	E	I	N	O	U	Y	?	!	\$
International Characters	â	Ç	é	ï	ñ	ô	ü	ÿ	¿	¡	¢
	ä	ç	ê	î	Ñ	ö	û	Ÿ	?	!	£
	ã	C	è	ì	N	ò	Ù	y			¥
	À	c	è	l	n	Ó	ú				f
	Ä		E	i		ó	U				\$
	æ		E			ö	u				
	Æ		e			Ó					
	á					o					
	à										
	À										
a											

Appendices

Appendix A — Sign diagnostic test


Your sign can do a self test to determine if all the LEDs are working properly.

Step	When you do this...	You see this...
1	Press PROGRAM .	
2	Press BACK until SET TIME AND DAY appears.	
3	Press ADV .	
4	Type <i>TEST</i>	The sign will go through a series a LED tests until PROGRAM is pressed again.
5	Press PROGRAM to exit the self-test mode.	

Appendix B — Updating the sign's firmware (EPROM)


From time to time it may be necessary to update the sign's internal firmware by replacing an EPROM inside the sign. To do this, follow these steps:

1. Remove power from the sign.




2. Replace the sign's internal EPROM according to this diagram:


1. Remove one screw from each of the L-brackets holding the sign's cap.



2. Lift up and remove the cap.



3. Pull up and remove the clear plastic lens on the sign's front.



4. To remove the current EPROM, grasp these two tabs and gently pull it out.

Then put in the new EPROM.







Figure 3: How to change the sign's EPROM

3. Re-assemble the sign, being careful not to catch any wires. Then re-apply power to the sign.

Appendix C — Transferring a sign's memory from one sign to another


You can transfer the messages from the memory of one sign to the memory of any another signs by completing the following steps.

NOTE: To complete the transfer of memory from one sign to other signs, all signs must be connected together and all must have the RS232/RS485 jumper set to RS485. For further information on connecting signs, see the **Network Configurations** manual, PN 9708-8046.


Step	When you do this...	You see this...
1	Press PROGRAM .	
2	Press SPECIAL .	
3	Press D .	
4	The sending sign transmits all messages to the receiving sign(s) and then resumes displaying messages as programmed.	

Quick Reference Card

Message control keys

	
PROGRAM	To turn the sign on or off, hold down SHIFT and then press PROGRAM . To enter messages, set the date and time, clear memory, etc., press PROGRAM and then BACK until the setting you want to change is shown. Then press ADV to change that setting.
RUN	Press twice to exit PROGRAM mode.
APPEND	Not used.
CURSOR	Not used.
SPECIAL	Not used.
FONT	Changes between a small or large font.
WIDTH	Not used.
COLOR	Changes the color of text.

Display modes and special keys

	
ROLL	Not used.
WIPE	Hold down SHIFT and press 2 to use the Wipe mode in a message. Doing this more than once cycles through all the options for direction of the wipe.
SCROLL	Not used.
FLASH	Hold down SHIFT and press 4 to use the Flash mode in a message.
HOLD	Hold down SHIFT and press 5 to use the Hold mode in a message.
ROTATE	Not used.
AUTO	Hold down SHIFT and press 7 to use the Auto mode in a message.
SPEED	Hold down SHIFT and press 8 to use the Speed mode in a message. Doing this more than once cycles through all the options for speed. (SP1 = slowest, NHL = fastest).
TIME	Hold down SHIFT and press 9 to include the time in a message.
Date	Hold down SPECIAL and press M to include the date in a message.